Description	***Part Number***
1. Output Filter Capacitor Assembly	C006
2. Air Filter	AF-P100
3. Output Coil	AZF300-70
4. Fuse	T2AL250 VP (2)
5. Measurement Board	A120
6. Battery for Main Control	M4T28BR12SH1
7. Reprogram Main Board and add battery	REPROGRAM
8. Aircraft Cable with special configuration for remote sense cables, and on/off	CS-30RSL (note 2)
9. Pit connector replacement sleeves	CS-PC-1223
10. Replaceable Nose piece	CS-NP-1223
11. Rectifier Stack Rebuild	AJS90R
12. Inverter Stack Rebuild	AJS90I
13. Breaker Handle	AJS90CBH
14. Driver Board	CS060-M971
15. Pre-charge Board	CS060-M970
16. Voltage Monitoring Relay, 42V	CS240-M151
17. Main Control Board	061-M955
18. Remote Service Point Rewire	RSPRW

Description	***Part Number***
19. Digital AC Current Meter	210-M114A
20. Digital AC Volt Meter	210-M113A
21. Digital Frequency Meter	210-M115
22. Single Transistor Drive Card	061-M378
23. Single Transistor, Recovery Module	150-M174
24. Dual Transistor Drive Card	061-M350-A
25. Dual Transistor	150-M102
26. Voltage Control Board	061-M200
27. Analog Board	061-M275
28. Light Bulbs, Control Panel	100-M100
29. Fan	380-M020
30. Fault Display Board	061-M300
31. SCR	140-M086
32. SCR Drive Card	061-M400
33. SCR Heatsink Rebuild	SCRHSNKRBLD
34. Output Capacitor Assembly	068-M010
35. Remote Service Point Rewire	RSPRW
36. 15 VDC Regulator	170-M164
37. Control Logic Board	061-M100
38. DC Buss Capacitor	120-M193
39. Output Filter Capacitor	120-M214A
40. Output Filter Capacitor	120-M215A
41. Enclosure Door Compress Latch	440-M194
42. Inverter Heatsink Rebuild	INVHSNKRBLD
43. ETM (Elapsed Time Meter)	210-M110
44. Output Contactor & Adapter Plate	231-M046